




'Tradie Tuff'


COMMERCIAL ROOF RACKS

FORD TRANSIT CUSTOM SWB & LWB,
02/2014 - ON

FIXED MOUNT



PART NUMBER: VAS.RC1056, VAS.RA1056, VAS.RC1042, VAS.RA1042, VAS.RC1220, VAS.RA1220, VAS.RC1221, VAS.RA1221, VAS.RC1039, VAS.RA1039, VAS.RC1040, VAS.RA1040, VAS.RC1031, VAS.RA1031, VAS.RC1037, VAS.RA1037, VAS.RC1048, VAS.RA1048, VAS.RC1019, VAS.RA1019.



Note:

- PLEASE READ INSTRUCTIONS AND CHECK CONTENT PRIOR TO INSTALLING.
- PLACE INSTRUCTIONS IN VEHICLES GLOVE COMPARTMENT AFTER INSTALLING.



3 Bar maximum capacity: 100kg

Tested to AS/NZS 1235-200 ADR standards

- Please check your vehicle's manual for vehicle load capacity (please do not exceed the lowest load rating) and please download and read our Load Rating guide which can be found on our website vas.com.au.
- Load rating is based on driving on sealed roads to road conditions and includes weight of roof rack system.


Important information

- Complete maintenance checks weekly including bolt connections and tightness.
- Heavy loads carried near feet
- Overhanging loads should conform to relevant state laws
- Check tie down strap tension every 50klm as loads can shift
- Specialised equipment carriers such as ladder slides should be used
- Ensure your roof racks, ladder rails and or load does not inhibit the tailgate lifting on vehicles manufactured with these doors
- Check car park heights before entering
- Keep load under the maximum capacity
- Use non stretch fastening straps
- Remove roof racks prior to using an automatic car wash

Note: The handling characteristics of a vehicle will change when a carrier system is fitted. Driving technique such as speed reduction, cornering techniques and braking distances should be altered to allow for these changes.

Kit Inclusions

Item	Part	3 Bar
1	M6 x 30mm Button Head Screw - F008	12
2	M6 Spring Washer - F012	12
3	M6 x 16mm Flat Washer - F011	12
4	M8 x 16mm Button Head screw - F016	12
5	M8 Spring Washer - F018	12
6	M8 x 17mm Flat Washer - F017	12
7	Right Bracket - C085	2
8	Left Bracket - C086	2
9	Rear Right Bracket - C189	1
10	Rear Left Bracket - C190	1
11	4mm Allen Tool - C028	1




Tools Required

- 1 - Flat Blade Screw Driver.
- 2 - Butyl Mastic.
- 3 - 5mm Allen Key.
- 4 - T40 Torx Key.
- 5 - 4mm Allen Tool (provided).



Required kits (as separate):

- Crossbar x3 1500mm
- 10mm Spacer x 4
- Crossbar Mount Kit x3



Step 1


Identify the factory crossbars mounts on the roof of the vehicle.




Step 2

1 - Using a screw driver, remove the cover from the factory crossbars. 2 - With a T40 torx-key, remove the screws and the crossbars from the roof. Store in a safe place. 3 - Apply butyl mastic to each exposed thread in the roof.


1:



2:





3:



3


Step 3

1 - Install the M8 hardware into each bracket. 2 - Place the assemblies over the exposed mounting points in the roof. Tighten the assembly with a 5mm allen key.



Step 4

Complete crossbar mount kits as specified in their instructions. Place the crossbars onto the installed brackets in the roof. Fix in place with the M6 hardware provided and tighten with the allen key provided.



NOTE

ATTENTION:

Thoroughly check all fasteners are secure before driving away. Heights are for standard unloaded vehicles. Always check your specific vehicles height.

